

BUDDY Ranger

Integrated Weight Instructions

!!WARNING!!

INCORRECTLY LOADED POUCHES


WILL NOT BE SECURE

PLEASE READ INSTRUCTIONS CAREFULLY


The loading technique should be practiced.

When properly secured the pouches will withstand a vigorous pre-dive shake test.


Side Pouches




Secure the weights in the pouch using the Velcro Tabs.




Insert the pouches in to the pockets. There is an "L" on the left-hand pouch. Make sure the stiffened back is on the inside.




Velcro toggle in central position and close flap.




YOU MUST ENSURE the flap is tucked underneath the outer edge (top & bottom), inserted as far as possible and properly secured.




Showing CORRECT loading of pouch with flap tucked under outer edge top & bottom




To remove pouches: pull on toggles




Secure a lead weight or lead shot pouch in the pocket




Fold down top flap as far as possible



Fold the second flap (with Velcro on both sides) over the first



Ensure the second flap is tucked right under the third flap



Finally, fold the third flap over the other two

Please Note:

It is the responsibility of every diver to ensure their own weight configuration is correct. Therefore, it is necessary to experiment with quantity and distribution of lead - as taught by the various dive training agencies - to perfect in-water positioning and heads-up surface support (With an 'empty' cylinder At the end of the dive. Consult an appropriately Qualified instructor for advice.